IWILL® H2107™ SERIES

2-Way Server Barebone
Hardware Installation Guide

Preface

Operation is subjected to the following two conditions

1. This device may not cause harmful interference
2. This device must accept any interference received, including interference that may cause undesired operation.

IWILL® Corp. makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose.

IWILL® Corp. shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

IWILL® Corp. assumes no responsibility for the use or reliability of its software on equipment that is not furnished by IWILL® Corp.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this publication may be reproduced, transcribed, stored in a retrieval system, translated into any language or computer language, or transmitted in any form whatsoever without the prior written consent of IWILL® Corp.

Copyright© 2005 by IWILL® Corp. All rights reserved.

Other products and companies referred to herein the trademarks or registered trademarks of their respective companies or mark holders.

The information in this document is subject to change without notice.

FCC Compliance Statement

This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television equipment reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna
2. Move the equipment away from the receiver
3. Plug the equipment into an outlet on a circuit different from that to which the receiver is connected
4. Consult the dealer or an experienced radio/television technician for additional suggestions

You are cautioned that any change or modifications to the equipment not expressly approve by the party responsible for compliance could void your authority to operate such equipment.

This device complies with Part 15 of the FCC Rules.

CE Compliance Statement

Notice for Europe (CE Mark) This product is in conformity with the Council Directive 89/336/EEC, 92/31/EEC (EMC).

Table of Content

CHAPTER 1 GETTING STARTED 6

1-1 PACKING LIST 7

1-2 PRODUCT SKUS 8

1-3 OPERATING ENVIRONMENTAL REQUIREMENTS 8

1-4 BEFORE POWERING ON THE SYSTEM FOR THE FIRST TIME 9

1-5 ACTIVATING THE SYSTEM 10

1-6 ON LAST CHECK 10

CHAPTER 2 SYSTEM OVERVIEW 11

2-1 H2107 SERIES SERVER BAREBONE PLACEMENT 12

2-2 H2107 SERIES FEATURES HIGHLIGHT 13

System: *13*

System parts: *13*

2-3 H2107 SERIES MAIN BOARD LAYOUT 16

2-4 CABLE INSTALLATION 17

2-4.1 Rear Panel IO *17*

2-4.2 Front Panel IO *19*

CHAPTER 3 SYSTEM INSTALLATION 20

3-1 INTRODUCTION OF THE NECESSARY PARTS 21

3-2 INSTALLATION PROCEDURES 22

CHAPTER 4 HARDWARE INSTALLATION 24

4-1 HARDWARE INSTALLATION PROCEDURES 24

4-2 JUMPER SETTING AND INTERNAL CONNECTORS FOR MAINBOARD 25

4-2.1 PCI-X Switch Jumper *26*

4-2.2 VGA Disable *27*

4-2.3 Clear CMOS Header *28*

4-2.4 Front Panel Switch Header *29*

4-2.5 LAN LED Header *30*

4-2.6 Serial ATA Connector *31*

4-2.7 BMC Connector *32*

4-3 HEATSINK AND CPU INSTALLATION 33

4-3.1 CPU Installation *33*

4-3.2 Heatsink Installation *36*

4-4 INSTALL MEMORY 37
4-5 MEMORY INSTALLATION PROCEDURES 38
4-6 EPS POWER SUPPLY 40
4-7 INSTALL EXPANSION CARDS 41
4-7.1 Expansion Card Installation Procedure 41
4-7.2 Assigning IRQs for PCI Expansion Cards 41
4-7.3 PCI-Express Riser Card 42
CHAPTER 5 BIOS SETUP 43
5-1 STARTING BIOS SETUP 44
5-2 UPDATING BIOS SETUP 45
5-3 USING SETUP 47
5-4 MAIN MENU 49
5-5 ADVANCED MENU 49
5-5.1 CPU Configuration Submenu 50
5-5.2 IDE Configuration Submenu 50
5-5.3 Floppy Configuration Submenu 51
5-5.4 Super I/O Configuration Submenu 52
5-5.5 Hardware Health Configuration Submenu 52
5-5.6 Hyper Transport Configuration Submenu 53
5-5.7 MPS Configuration Submenu 53
5-5.8 PCI Express Configuration Submenu 54
5-5.9 Remote Access Configuration Submenu 54
5-5.10 USB Configuration Submenu 55
5-5.11 The Advanced setting description 56
5-6 PCI PNP MENU 57
5-7 BOOT MENU 59
5-7.1 Boot Settings Configuration Submenu 61
5-8 SECURITY MENU 62
5-9 NORTHBRIDGE CHIPSET CONFIGURATION MENU 65
5-9.1 Memory Configuration Submenu 66
5-9.2 ECC Configuration Submenu 68
5-9.3 IOMMU Mode Submenu 69
5-10 POWER MENU 70
5-11 EXIT MENU 71
CHAPTER 6 TECHNOLOGY SUPPORT 73

Chapter 1 Getting Started

Congratulations on your purchase of the H2107 Series Server Barebone. Inside 1U rackmount chassis, there is an extremely huge computing power from two AMD Opteron™ processors. The main board of H2107 is based on AMD platform. It is a dual AMD® Opteron micro-Socket 940 motherboard (M/B) based on the NVIDIA® nFORCE™ Professional 2200 MCP chipset. H2107 provides a PCI-Express x8 slot that the transfer speed can reach maximum 4.5GB/Sec.

The H2107 Series Server Barebone supports up to sixteen memory DIMMs (eight for each processor installed) accommodating up to 32 GB of memory using registered PC3200/2700/2100 ECC DDR memory modules.

Flexibility and expandability are provided by one PCI-Express riser card. This PCI slot enables to enter in one add-on card.

Additional features such as onboard dual Broadcom® PCI-express Gigabit Ethernet controller and ATi Rage XL video controller providing the highest system capabilities that meet a wide range of demanding workstation and server applications.

IWILL H2107 provides two 3.5 drive bays and one slim-type CD-ROM bay. It could support two SATA or SCSI interface hard drive disks with RAID 0, 1 function.

1-1 Packing list

Remove all items from the box and make sure you have these following items:

1.	H2107 Series Server Barebone
2.	IWILL® H2107 Series Server barebone hardware installation guide (This Document)
3.	One power cord
4.	One PCI-Express Riser Card
5.	One PCI-X Riser Card
6.	Power Installation CD Kit (including drivers and software)
7.	One set of CPU heatsink
8.	One set of chassis sliding rail. One set includes two rails.
9.	Intelligent Platform Management Interface user's guide and installation CD (Optional)

Please check the quantity of cables and module boards that come assembled inside the H2107 Series system.

Cable

- 1 x USB cable
- 1 x Power Light cable
- 1 x IDE cable for the CD-ROM device
- 2 x SATA cables (H2107 and H2107-B)
- 1 x SCSI cable (H2107-A and H2107-C)

Board

- 1 x DK88 Board
- 1 x BMC card (Optional)

Important

If there are any missing parts, please contact your retailer immediately.

1-2 Product Skus

Model Name	Storage Type	Power Supply
H2107	SATA	520W power supply
H2107-A	SCSI	520W power supply
H2107-B	SATA	400W power supply
H2107-C	SCSI	400W power supply

1-3 Operating Environmental Requirements

To ensure the reliability and performance of H2107 Series Server Barebone, please maintain the operating environment described below:

1. The ambient operating temperature is 0°C to 40°C
2. The relative humidity of operation is 10% to 85% non-condensing.

Be aware of the airflow for H2107 Series Server Barebone! The H2107 Series Server Barebone uses forced direct-airflow to cool the system. The above operating conditions should be maintained for reliable operation. In order to avoid conditions which may lead to overheating, please do not let heated exhausted air from other equipment enter:

1. The front of the rack or the cabinet
2. The access panels of the server.

Leave your system in the shipping crate at its final destination for 24 hours in the environment where you will set it up. This is to prevent thermal shock and condensation. To minimize the chance of system failure, use the server within the optimal temperature and humidity ranges as follow:

1. The optimize ambient temperature of operating is required as 21°C to 23°C
2. The optimize relative humidity of operating is 45% to 50% non-condensing.

1-4 Before powering on the system for the first time

H2107 Series is provided with a powerful power supply unit. Locate and connect the AC power cords to the system and an AC power source. There is one power unit in the right of H2107 Series system. Please see the below illustrations to install your power system.

Note

As the figure 1, you must install the power cord into the power module before you powering on the system. Figure 2 is showing how to connect the power cable to the receptacle.

Figure 1

Figure 2

1-5 Activating the System

After connecting the power cord to the system and AC source, the system can be powered on by pushing the power on button show below.

Turn On/Off

Reset



1-6 On last check

Before powering on the system for the first time it is helpful to avoid any problem by performing one last check. Make sure all AC power is installed and that no parts have dropped down into the system.

Chapter 2 System Overview

This chapter covers the installation of the system, cabling and system layout.

The system specification section will cover the most detail features for the CPU board, IO board, and chassis. This chapter also contains the specifications for the supported processors and memory required for this system.

The cabling section will cover the connection and installation for the related devices such as the serial connector, D-sub 15-pin VGA connector, USB connectors, Ethernet Gigabit connectors, and PS/2 connectors at the back and front panels.

2-1 H2107 Series Server Barebone Placement

A	1 x PCI-X or PCI-Express Expansion slot from a 1U riser card
B	2 x AMD 940 Pin Opteron™ processors with IWILL Heatsink
C	EPS 12V 520W Power (400W for H2107-B and H2107-C version)
D	Support 16 x ECC Registered DDR Memory up to 32GB
E	Support 2 x hot-swap HDD space bays
F	Support 1 x slim-type CD-ROM space bay
G	40*40*28mm 13000RPM fans (Double layer for H2107 and H2107-A) (Single layer for H2107-B and H2107-C)

2-2 H2107 Series Features Highlight

System:

Chassis Type	● 1U Server Chassis
CPU Type	● Dual AMD Opteron™ Processor 200 series
Memory Type	● 16 DIMMs Registered memory modules up to 32 GB
Drive Bays	● Support 2 X 3.5" hot-swap HDD spaces ● Support 1 x Slim-type CD-ROM space
Power Supply	● 520W EPS 12V power (H2107 and H2107A) ● 400W EPS 12V power (H2107-B and H2107-C)
External IO	● USB x 3 (2 ports at the rear panel, and 1 port at the front panel) ● LAN x 2 ● PS/2 connectors x 2 ● COM port x 1 ● VGA port x 1

System parts:

Chassis:

Chassis Type	● 1U Server Chassis
Chassis Dimension	● W: 19" x H: 1.75" x D: 27"
Chassis Material	● SPCC
System FAN (H2107-B and H2107-C)	● 5 x Middle 40*40*28mm 13000RPM fans
System FAN (H2107 and H2107-A)	● 4 x Middle 40*40*28mm (double layer) 13000RPM fans ● 1 x Middle 40*40*28mm (single layer) 13000RPM fans
HDD Placement	● Support 2 X 3.5" hot-swap HDD spaces ● Support 1 x Slim-Type CD-ROM

Mainboard:

Processor	● Two PGA 940 pin sockets ● Support up to two AMD Opteron™ processors

System Memory	● Support ECC Registered DDR SDRAM memory module ● Support up to 32GB memory capacity ● 128MB/256MB/512MB/1GB/2GB per DIMM ● Support DDR400/333/266 ● Total Sixteen 184pin 2.5V DIMM slots
Chipset	● NVIDIA nForce™ Professional 2200 ● AMD 8132 PCI-X 2.0Tunnel chip ● Winbond W83627THF Super I/O chip ● Analog Device ADM 1026 hardware monitor
Graphics	● Integrated ATI Rage XL w/ 8MB RAM Video Controller
LAN	● Dual Broadcom PCI-E 5721 Gigabit Ethernet Controllers ● Dual RJ-45 ports at the rear panel
On board IO	● One floppy connector ● One 9 pin serial port connector ● Three internal USB 2.0 headers ● Power, HDD and LAN LED pin headers ● One BMC connector
Rear Panel IO	● Two PS/2 connectors for mouse & keyboard ● Two USB 2.0 connectors ● One 9 pin serial port connector ● One 15 pin VGA connector ● Two RJ-45 Giga-bit ports
Expansion Slots	● One PCI-Express x8 slot (By 1U riser card) ● Or one PCI-X 64/133 slot (By 1U riser card)
BIOS	● AMI BIOS 8.0 on 4Mbit flash ROM ● Support APM 1.2 and ACPI 1.0
System Management	● Support IWILL® Server Management BMC card

	● Support IPMI 1.5 ● Support KCS interface for inband management ● Support RMCP protocol for out-of-band management
IPMI	● BMC Module
Other	● Support AC power failure ● 8 Layer design

2-3 H2107 Series Main Board Layout



1	Dual AMD Opteron™ Processors	**6**	BMC Connector
2	Dual Channel DDR Registered Memory	**7**	PCI Express x16 slot (x8 bandwidth)
3	AMD® 8132 PCI-X 2.0 Tunnel	**8**	PCI-X 64bits 64/100 MHz
4	ATi Rage XL video controller	**9**	PCI Express x8 slot
5	PCI-X 64bits 64/100/133MHz	**10**	NVIDIA nForce™ Professional 2200 MCP

* H2107 only provides one expansion slot space. You could install either PCI-Express add-on card or PCI-X add-on card only by different 1U riser cards.

2-4 Cable Installation

2-4.1 Rear Panel IO

This is an illustration of the Mainboard rear I/O port array.



PS/2 Mouse Connector (6-pin Female)

The system will direct IRQ12 to the PS/2 mouse if one is detected. If no mouse is detected, IRQ12 will be free for expansion cards to use.

PS/2 Keyboard Connector (6-pin Female)

This connection is for standard keyboards using a PS/2 (mini DIN) plug. This connector will not accept standard AT size (large DIN) keyboard plugs. You may need a DIN to mini DIN adapter for standard AT keyboards.

USB Port Function

H2107 Series server system provides the two USB 2.0 ports at the rear panel. USB 2.0 supports 480Mb/second bandwidth providing a marked improvement in device transfer speeds between your computer and a wide range of simultaneously accessible external Plug and Play peripherals. You can connect or disconnect USB cables when the system is turned on.



Serial Port Function

The serial ports are RS-232C asynchronous communication ports with 16C550A-compatible UARTs that can be used with modems, serial printers, remote display terminals, and other serial devices. It can operate at speeds up to 115,200bps. You can configure the port's speed in the computer's Operating System.

VGA Port Function

The VGA port is for the image output. It can be used with the PC monitor devices.

LAN Port Function

The LAN port uses a CAT 5 LAN cable for connecting the motherboard to a local area network by means of a network hub. The port has 2 indicator LEDs.

Speed LED (right)

• 10Mbps - will not blink

• 100Mbps - LED is green

• 1000Mbps - LED is orange

Link and Activity LED (left)

• LED is yellow when the LAN connection is linked and accessed.



2-4.2 Front Panel IO



USB Port Function

H2107 Series server system provides one USB 2.0 port at the front panel. You can connect or disconnect USB cables when the system is turned on.

Front Section diagram



A	1 x CD-ROM Bay
B	2 x hot-swap HDD bays
C	IO Array

Chapter 3 System Installation

This chapter mainly covers how to install your system, H2107, to your rack housing on the server room. It will describe how to install the slide rail.

This section also introduces the necessary parts of rackmount kit for H2107 Series Server Barebone. Refer to the following illustration for the H2107 Series Server Barebone installation.

3-1 Introduction of the Necessary Parts

	2 x H2107 Series Server System Mounting Channel
	2 x Inner Rails
	4 x “L” Shaped Bracket
	1 x H2107 Series Server Barebone

3-2 Installation Procedures

1. Disassemble the slide rail



2. Assemble the inner rail onto chassis



3. Mount L shape and external rail to rack frame.



4. Insert the chassis into cabinet



Chapter 4 Hardware Installation

This chapter covers processor and memory installation and hardware configuration.

4-1 Hardware Installation Procedures

Installation procedures will be broken down into six major parts.

Step 1: Set jumpers

Step 2: Install memory (DDR memory modules)

Step 3: Install AMD Opteron™ Processors

Step 4: Attach cables to connectors

Step 5: Install expansion cards

Step 6: Connect AC power

Warning

This H2107 Series Server Barebone contains sensitive electronic components that can be easily damaged by static electricity. Follow the instructions carefully to ensure correct Installation and to avoid static damage.

4-2 Jumper Setting and Internal Connectors for Mainboard

This section covers the jumper setting. Refer to the following illustration for the location of the jumpers.



1	PCI-X_2 Switch	**6**	PWR Button
2	PCI-X_1 Switch	**7**	Reset Button
3	VGA Disable	**8**	Front Panel Switch Header
4	Clear CMOS Jumper	**9**	LAN LED Header
5	Chassis Intrusion		

4-2.1 PCI-X Switch Jumper

H2107 Series provides two PCI-X slots. By the jumper setting, the slots can be up to 133 MHz or down to 66MHz. Please follow the below instruction.



PCI-X 1 Slot **PCI-X 2 Slot**

、 **PCI-X 1 Switch** **PCI-X 2 Switch**

	133MHz	100MHz	66MHz
1	off	on	off
2	off	off	on



1 Off; 2 Off – 133MHz



1 On; 2 Off – 100MHz



1 Off; 2 On – 66MHz

4-2.2 VGA Disable

This header lets you set your VGA function. When you short this jumper, the onboard ATi video controller would stop work. Then, you have to enter in an additional graphic card.



Short	Normal
Disable	Enable (Default)

4-2.3 Clear CMOS Header

The onboard button cell battery powers the CMOS RAM. It contains all the BIOS setup information. Normally, it is necessary to keep the jumper connected to pin1 and pin2 (Default) to retain the RTC data as shown below.



1-2	2-3
Normal (Default)	Clear CMOS

Follow these instructions to clear the CMOS RTC data:

1. AC off.
2. Short pin2 and pin3 with a jumper for a few seconds.
3. Replace the jumper on pin1 and pin2.
4. Turn on your computer by pressing the power-on button.
5. Hold down <Delete> during boot and select either the <Load Optimal Defaults> or <Load Failsafe Defaults> option in the selection "Exit". Then re-enter BIOS setup to re-enter user preferences. Refer to Chapter 5 BIOS SETUP for more information.

4-2.4 Front Panel Switch Header

PWR LED

This connector connects to the system's Power LED. When the system's power is on, this LED will light.

HDD Activity LED (2-pin HDD_LED)

This connector supplies power to the chassis's HDD/IDE activity LED. Read and Write activity by devices connected to the Primary or Secondary IDE connectors will cause the front panel LED to light up.

PWR Switch

This switch connects to the system's Power button allowing you to power on and off the system. You can configure the system to use the keyboard or mouse to power-on the system. You can also configure the system to respond to power restoration after a power outage occurs. These functions can be configured by making appropriate settings in the Integrated Peripherals submenu ("Super IO Device" field) of the BIOS.

Reset Switch (2-pin RST)

This 2-pin connector connects to the chassis-mounted reset switch for rebooting your computer without turning your power switch off and on. This is a preferred method of rebooting your system to prolong the life of your system's power supply.



4-2.5 LAN LED Header

This header is used to connect the RJ-45 LAN ports for the front panel. It can show the LAN speed status to the users in different light colors.

Pin 1 LAN1_Active LED	Pin 2 LAN1_Link LED
Pin 3 LAN1_Link 100	Pin 4 LAN1_Link 1000
Pin 3 LAN2_Active LED	Pin 5 LAN2_Link LED
Pin 6 LAN2_Link 100	Pin 7 LAN2_Link 1000
Pin 8 Power	Pin 9 Power



4-2.6 Serial ATA Connector

H2107 supports up to 4 SATA devices each with data transfer rates of 300MB/s. Four Serial ATA ports are supported by nForce™ Professional 2200 MCP. This Main board features four Serial ATA ports for four Serial ATA devices. It uses point to point technology, and supports hot swap. This chipset also supports RAID 0, 1, and 10, which are defined as follows:



RAID Type	Description
RAID 0	Striping: high performance, designed to connect multiple drives to act as one
RAID 1	Mirroring: writes data to two drives at once in case one drive fails, the other one will be a complete replica and can continue on. Full fail-over
RAID 10	Combination of RAID 0 and 1: over 4 drives, The drives are split in half and striped together, and the 2 new striped drives are then mirrored.



Serial ATA Drive Connectors

SATA Pin assignments	
Pin	**Description**
1	GND
2	RXP
3	RXN
4	GND
5	TXN
6	TXP
7	GND

Important

H2107 supports special NVRAID utility. About NVRAID detail information and user's manual, please visit IWILL® website: www.iwill.net, or NVIDIA® website: www.nvidia.com

4-2.7 BMC Connector

H2107 supports Intelligent Platform Management Interface. The IPMI specification defines an internal management bus for extending platform management within a chassis. IPMI functions include remote management access over Serial/Modem and LAN connections, and the capabilities for automatic alerting and recovery.

Installation Procedures

1. Before you enter in your BMC card on the DNS-SATA board, please match each pin's position.

Rear of BMC card



On board Connector

2. Be gently entering BMC card.



4-3 Heatsink and CPU Installation

4-3.1 CPU Installation

System mainboard accommodates AMD Opteron™ micro-PGA Socket 940 processors at 2000 MT (Mega Transfer per second). You must insert a CPU into CPU socket 0 (CPU0) first before installing one in CPU socket 1 (CPU1).



Note

As with all computer equipment, the processor and motherboard components may be damaged by electrostatic discharge (ESD). Please take proper ESD precautions when handling any board.

Warning

Do not apply voltage until the heatsink is fully installed. If voltage is applied before the heatsink is fully installed, the processor will overheat and failure will result. Read through the entire installation instructions completely to make sure you understand them before you begin.

Follow these instructions to install the CPU.

1. The socket locking lever must be raised (Pull out slightly, and then lift up).



2. Locate the pin 1 of the CPU socket and pin 1 of the CPU. (marked by a triangular hole in the Pin 1 corner)





3. Lower the locking lever and latching it into the fully locked position.



4-3.2 Heatsink Installation

1. Apply thermal grease to the top of the CPU. Please spread the grease evenly in order to quickly conduct the heat away the processors.
2. Mount the CPU heatsink to the top of the CPU and socket as shown in the following illustration.

Secure one side to the motherboard Secure the opposite side



3. Please follow the number sequence to drive in four screws in order to fix the heatsink well. However, please DO NOT tightly drive in them before you finish all the procedures.
4. After you gently drive in all of screws, please keep the heatsink balance. Then, you can tightly drive in them.
5. If you feel the system is overheating, please shut down the system. Make sure the heatsinks are mounted securely.

Tip

Make sure that you use the heat-spreading paste between the heatsink and the integrated heat spreader of the processors.

Warning

Keep the force balanced on both sides of the heatsink when you install the heatsink for CPU or the heat pipe will be bent!

4-4 Install Memory

The system mainboard uses Dual Inline Memory Modules (DIMM). Two pair's banks are available; each bank supports one CPU with Hyper Transport Technology. The memory DIMMs accommodates PC2100/2700/3200 (DDR266/DDR333/DDR400) and Double Data Rate Memory (DDR) memory modules in 128MB, 256MB, 512MB, 1GB, and 2GB combinations. Total memory size for one mainboard is between 128MB and 32GB.

Important

The system mainboard has strict memory type and timing requirements. Before you purchase DDR (Double Data Rate) memory for using in the system mainboard, you should contact your local reseller for a recommend list of system memory that has been validated on this system.

Important

To take advantage of the 128-bit interface, you must install DIMMs in pairs of two (2). DIMM0 and DIMM1 are paired, and DIMM2 and DIMM3 are paired; DIMM4 and 5 are paired, and DIMM6 and 7 are paired. If you only install two DIMMS into a Memory bank, it is recommended that you install them in slots DIMM0 and DIMM1 to get the full bandwidth. It's not necessary to install full memory onto both CPU0 and CPU1 memory banks. You could choose to install onto either CPU0 memory bank or CPU1 memory bank when there are two processors on board.

Two DDR Modules	HO DIMM0, HO DIMM1
Four DDR Modules	HO DIMM0, HO DIMM1, HO DIMM2, HO DIMM3
Six DDR Modules	HO DIMM0, 1; HO DIMM2, 3; HO DIMM4, 5
Eight DDR Modules	HO DIMM0, 1; HO DIMM2, 3; HO DIMM4, 5; HO DIMM6, 7

4-5 Memory Installation Procedures

1. Locate the DIMM modules



2. Make sure the DIMM's pins are facing down, and check that the pin arrangement on the memory module resembles the one pictured below.



Important

Always populate H0 DIMM socket before installing memory modules in the H1 DIMM sockets.

3. Insert the module into the DIMM socket and press down evenly on both ends firmly until the DIMM module is securely in place. (The tabs of the DIMM socket will close-up to hold the DIMM in place when the DIMM is properly installed into the socket.)





4-6 EPS Power Supply

These 24-pin connectors connect the server board to the EPS power supply. Find the proper orientation and push down firmly to make sure that the pins are aligned. The 8-pin connector provides a dedicated power supply for the CPUs.



Important

IWILL® always recommends our customers use EPS12V Power supplies. For any power damaged, please contact your retailer or IWILL® technicians.

4-7 Install Expansion Cards

Warning

Please power off your power supply completely when adding removing any expansion card or other system components. Failure to do so may cause severe damage to both your motherboard and expansion card.

4-7.1 Expansion Card Installation Procedure

1. Read plate on the slot you intend to use. Keep the bracket for possible future use.
2. Carefully align the card's connectors and press with the riser card firmly.
3. Secure the card on the slot with the screw you removed above.

4-7.2 Assigning IRQs for PCI Expansion Cards

An IRQ number is automatically assigned to PCI expansion cards. In the PCI bus design, the BIOS automatically assigns an IRQ to a PCI slot that contains a card requiring an IRQ. To install a PCI card, you need to set the INT (interrupt) assignment. Since all the PCI slots on this motherboard use an INTA #, set the jumpers on your PCI cards to INTA.

4-7.3 1U Riser Card

Inside the system package, there are a PCI-Express and PCI-X Riser Card. This Riser Card can make you to plug your PCI-Express or PCI-X add-on card in the horizontal direction. Please follow the below illustrations to install or replace riser cards.

A. PCI-Express and PCI-X slots will be both occupied by IWILL proprietary PCI-Express riser card. Please gently enter in this riser card before you power on your system.





B. IWILL PCI-X riser card will be installed into PCI-X 64/133 slot that would be also used for installing IWILL PCI-Express riser card. It means you could only install either PCI-X or PCI-Express riser card at the same time.



Chapter 5 BIOS Setup

This chapter discusses the AMI BIOS Setup program built into the ROM BIOS. The Setup program allows users modifying the basic system configurations according to their requirements. This special information is then stored in battery-backed RAM so that it retains the Setup information when the power is turned off.

The AMI BIOS installed in your computer system's ROM (Read Only Memory) is a custom version of an industry standard BIOS. The BIOS provides critical low-level support for standard devices such as disk drives and serial ports.

The AMI BIOS has been customized by adding important, but non-standard, features such as password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

The rest of this chapter is intended to guide you through the process of configuring your system using Setup.

5-1 Starting BIOS Setup

The AMI BIOS is immediately activated when you power on the computer every time. The BIOS reads the system information contained in the CMOS and begins the process of checking out the system and configuring it. After finishing configuring the whole system, then BIOS will continue to seek an operating system on one of the disks, launch then turn control over to the operating system.

While the AMI BIOS is in control, the Setup program can be activated in the way:

By pressing the <DEL> key when the following message appears briefly at the bottom of the screen during the POST (Power On Self-Test).

5-2 Updating BIOS Setup

- Creating a bootable floppy disk

A、 DOS environment

Insert a 1.44 MB floppy disk into the drive.

At the DOS prompt, type:

format A:/S then press <Enter>.

B、 Microsoft® Windows® environment

Insert a 1.44 MB floppy disk into the floppy disk drive.

From your Windows desktop, click on Start, then select My Computer.

Select the 3 1/2 Floppy Drive icon.

Click File from the menu, and then select Format. A Format 3 1/2 Floppy Disk window appears.

If you are using Windows™, select “Create an MS-DOS startup disk” from the format options field, then click Start.

- Move the latest BIOS file to the bootable floppy disk.
- Using “AMIFLASH.EXE” to update the BIOS

Update the BIOS using the AMIFLASH.EXE utility in DOS environment.

1. Visit the IWILL website (http://www.iwill.net) to download the latest BIOS file for your motherboard. Save the BIOS file to a bootable floppy disk.
2. At the DOS prompt, type the command line:
   AMIFLASH / <filename>
   where “filename” means the latest (or original) BIOS file that you copied to the bootable floppy disk. The screen displays the status of the update process.

Note

IWILL H2107 server does not provide a space for an internal floppy device, so, we suggest that you could install a USB-interface floppy outside of the chassis.

Important

The BIOS information on the screen is for reference only. What you see on your screen may not be exactly the same as shown.

Warning

DO NOT shutdown or reset the system while updating the BIOS! Doing so may cause system boot failure! Make sure to set protection BIT disable before flash BIOS.

3. When the BIOS update process is complete, the utility returns to the DOS prompt.

The AMI BIOS is immediately activated when you power on the computer every time. The BIOS reads the system information contained in the CMOS and begins the process of checking out the system and configuring it. After finishing configuring the whole system, then BIOS will continue to seek an operating system on one of the disks, launch then turn control over to the operating system.

While the AMI BIOS is in control, the Setup program can be activated in the way:

By pressing the <DEL> key when the following message appears briefly at the bottom of the screen during the POST (Power On Self-Test).

- Press <DEL> to enter SETUP

5-3 Using Setup

In general, you use the arrow keys to highlight items, press <Enter> to select, press <Esc> to quit. The following table provides more details about how to navigate in the Setup program using the keyboard.

Key	Function
Up Arrow(↑) Key	Move to the previous item
Down Arrow(↓) Key	Move to the next item
Left Arrow(←) Key	Move to the previous item
Right Arrow(→) Key	Move to the next item
Esc key	In the Submenu: Exit the submenu. In the BIOS main category: Quit Without saving changes.
Enter Key	Select the item. A pop-up selection will display on the screen to set the item value.
PgUp Key	Previous page on Scrollable menus or jump to the first interactive item listed
PgDn Key	Next page on Scrollable menus or jump to the last interactive item listed
F1 Key	General Help on Setup navigation keys. Press <F1> key to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window, press <ESC> key or <F1> key again.
F2/F3 Key	Change colors
F7 Key	Discard changes
F8 Key	Load failsafe defaults
F9 Key	Load optimal defaults
F10 Key	Save and Exit
Home	Go to top of screen
End	Go to bottom of screen
Esc	Exit

IMPORTANT

The BIOS does NOT automatically save values that you have modified. If you do not save your values before you exit the BIOS Setup Utility, all your changes will be lost.

If after making and saving system changes with the BIOS Setup Utility, you discover that your computer is no longer able to boot, the AMI BIOS supports an override, which will reset your system to the Failsafe defaults. If that fails, it is possible to manually clear the present CMOS information through the "Clear CMOS Header" on the motherboard (Refer to Jumper Settings for more information).

The best advice is to ONLY alter settings which you thoroughly understand. The default settings have been carefully chosen by AMIBIOS to provide the maximum system performance and reliability. Even a slight change to the chipset setup may cause potential and unpredictable failure to the system.

5-4 Main Menu

This is the first screen that is displayed when you enter the BIOS Setup Utility. Each tab lined on the top of the screen represents each different menu. The following picture shows the main menu. Main menu shows the information of BIOS version, date and ID; processor type, speed and count; system size. In addition, system time and date is adjustable using + / - key or number keys.



5-5 Advanced Menu

You can make these modifications on the advanced menu.

5-5.1 CPU Configuration Submenu

In CPU configuration, you can set up CPU frequency and enable/disable the Error Reporting. GART error reporting should remain disabled for the normal operation.

BIOS SETUP UTILITY
Advanced
CPU Configuration
GART Error Reporting [Disabled]
MTRR Mapping [Continuous]
This option should remain disabled for the normal operation. The driver developer may enable it for testing purpose.
↔ Select Screen
↑↓ Select Item
+- Change Option
F1 General Help
F10 Save and Exit
ESC Exit
v02.58 (C)Copyright 1985-2004, American Megatrends, Inc.

5-5.2 IDE Configuration Submenu

You can make the selections on IDE Configuration menu.

BIOS SETUP UTILITY
Advanced
IDE Configuration
OnBoard PCI IDE Controller [Both]
▶ Primary IDE Master : [Not Detected]
▶ Primary IDE Slave : [Not Detected]
▶ Secondary IDE Master : [Hard Disk]
▶ Secondary IDE Slave : [Not Detected]
▶ Third IDE Master : [Not Detected]
▶ Fourth IDE Master : [Not Detected]
▶ Fifth IDE Master : [Not Detected]
▶ Sixth IDE Master : [Not Detected]
Hard Disk Write Protect [Disabled]
IDE Detect Time Out (Sec) [5]
ATA(PI) 80Pin Cable Detection [Host & Device]
SATA0 IDE Interface [Enabled]
SATA1 IDE Interface [Enabled]
First Boot Device from [P-ATA]
▶ Configuration nVidia RAID ROM
DISABLED: disables the integrated IDE Controller.
PRIMARY: enables only the Primary IDE Controller.
SECONDARY: enables only the Secondary IDE Controller.
BOTH: enables both IDE Controllers.
↔ Select Screen
↑↓ Select Item
+- Change Option
F1 General Help
F10 Save and Exit
ESC Exit
v02.58 (C)Copyright 1985-2004, American Megatrends, Inc.

Feature	Options	Description
OnBoard PCI IDE Controller	Disable Primary Secondary Both	Disable: disable the integrated IDE controller Primary: enable only the Primary IDE controller Secondary: enable only the Secondary IDE controller Both: enable both IDE controllers
Hard Disk Write Protect	Disable Enable	Disable/Enable the hard disk write protection. This will be effective only device is accessed through BIOS
IDE Detect Time out (sec)	0, 5, 10, 15, 20, 25, 30, 35	Select the time out value for detecting ATA/ATAPI device
ATA (PI) 80Pin Cable Detection	Host & Device Host Device	Select the mechanism for detecting 80 pin cable
SATA0 IDE Interface	Disable Enable	Disable/Enable the SATA0 IDE Interface
SATA1 IDE Interface	Disable Enable	Disable/Enable the SATA1 IDE Interface
First Boot Device from	P-ATA S-ATA	Choice the first boot device when you turn on the system

5-5.3 Floppy Configuration Submenu



Important

H2107 server does not provide any floppy bay, and it does not recommend using floppy devices.

5-5.4 Super I/O Configuration Submenu



5-5.5 Hardware Health Configuration Submenu

On this menu, you can monitor the system status. It would show the CPU and system temperature.

5-5.6 Hyper Transport Configuration Submenu



To set up the hyper transport speed and bandwidth, you can adjust over this menu. The incorrect manipulation will impede the system running.

5-5.7 MPS Configuration Submenu



5-5.8 PCI Express Configuration Submenu



Enable/Disable PCI Express L0 and L1 link power states.

5-5.9 Remote Access Configuration Submenu



5-5.10 USB Configuration Submenu



Adjust the USB speed on this submenu. There are two speeds, HiSpeed and FullSpeed, for your configuration.

5-5.11 The Advanced setting description

Feature	Options	Description
Floppy Configuration	Disabled 5 1/2” 360 KB 5 1/2” 1.2 MB 3 1/2” 720 KB 3 1/2” 1.44 MB 3 1/2” 2.88 MB	Select Floppy A or Floppy B and then selects floppy-diskette type installed in your system.
Hardware Health Configuration	Disable/Enable hardware health function and hardware thermal throttling	Enable/Disable hardware health function Thermal throttling allows the user to reduce CPU duty cycle to a user defined percentage when the temperature reaches a user defined value H/W health event
ACPI Configuration	ACPI Aware O/S Yes/No	Enable: O/S supports ACPI Disable: O/S doesn’t support ACPI
Hyper Transport Configuration	CPU0 : CPU1 HT Link Speed/Width	Hyper Transport link speed/width is adjustable
Remote Access Configuration	Disable Serial	Selects Remote Access type
USB Configuration	Legacy USB Support Disabled/Enabled/Auto USB Mass Storage Device Configuration	Enable support for legacy USB Auto option disables legacy support it no USB device connected Configure the USB mass storage class devices

5-6 PCI PnP Menu



PCI PnP Menu 1


BIOS SETUP UTILITY
Main Advanced PCIPnP Boot Security Chipset Power Exit
IRQ15 [Available]
DMA Channel 0 [Available]
DMA Channel 1 [Available]
DMA Channel 3 [Available]
DMA Channel 5 [Available]
DMA Channel 6 [Available]
DMA Channel 7 [Available]
Reserved Memory Size [Disabled]
Available: Specified DMA is available to be used by PCI/PnP devices.
Reserved: Specified DMA is reserved for use by legacy ISA devices.
↔ Select Screen
↑↓ Select Item
+- Change Option
F1 General Help
F10 Save and Exit
ESC Exit
vMM.mm (C)Copyright 1985-2002, American Megatrends, Inc.

PCI PnP Menu 2

Feature	Options	Description
Clear NVRAM	Yes No	Clear NVRAM during System Boot
Plug & Play O/S	Yes No	Yes: lets the O/S configure PnP devices not required for boot if your system has a Plug and Play O/S
PCI Latency Timer	32, 64, 96, 128, 160, 192, 224, 248	Value in units of PCI clocks for PCI device latency timer register
Allocate IRQ to PCI VGA	Yes No	Yes: Assign IRQ to PCI VGA card if card requests IRQ No: Doesn't assign IRQ To PCI VGA cars even if card requests IRQ
Palette Snooping	Enabled Disabled	Enabled: informs the PCI devices that an ISA graphics device is installed in the system so the card will function correctly
PCI IDE BusMaster	Enabled Disabled	Enabled: BIOS uses PCI busmastering for reading/writing to IDE drives
Offboard PCI/ISA IDE card	Auto PCI Slot1 PCI Slot2 PCI Slot3 PCI Slot4 PCI Slot5 PCI Slot6	Some PCI IDE cards may require this to be set to the PCI slot number that is holding the card
IRQ3~IRQ15	Available Reserved	Available: specified IRQ is available to be used by PCI/PnP devices Reserve: specified IRQ is reserved for use by legacy ISA devices
DMA Channel 0, 1, 3, 5, 6, 7	Available Reserved	Available: specified DMA is available to be used by PCI/PnP devices Reserve: specified DMA is reserved for use by legacy ISA devices
Reserved Memory Size	Disabled 16K 32K 64K	Size of memory block to reserve for legacy ISA devices

5-7 Boot Menu



Boot Menu 1: Boot Settings


BIOS SETUP UTILITY
Boot
Boot Device Priority
1st Boot Device [1st FLOPPY DRIVE]
2nd Boot Device [(Hard Drive)]
Specifies the boot sequence from the available devices.
A device enclosed in parenthesis has been disabled in the corresponding type menu.
↔ Select Screen
↑↓ Select Item
+- Change Option
F1 General Help
F10 Save and Exit
ESC Exit
v02.58 (C)Copyright 1985-2004, American Megatrends, Inc.

Boot Menu 2: Boot Device Priority



Boot Menu 3: Hard Disk Drives

Feature	Description
Boot Device Priority	Specify the boot device priority sequence
Hard Disk Drives	Specify the boot device priority sequence from available hard drives
Removable Drives	Specify the boot device priority sequence from available removable drives

5-7.1 Boot Settings Configuration Submenu

BIOS SETUP UTILITY
Boot
Boot Settings Configuration
Quick Boot [Enabled]
Quiet Boot [Disabled]
AddOn ROM Display Mode [Force BIOS]
Bootup Num-Lock [On]
PS/2 Mouse Support [Auto]
Typematic Rate [Fast]
Wait For 'F1' If Error [Enabled]
Hit 'DEL' Message Display [Enabled]
Interrupt 19 Capture [Disabled]
Allows BIOS to skip certain tests while booting. This will decrease the time needed to boot the system.
↔ Select Screen
↑↓ Select Item
+- Change Option
F1 General Help
F10 Save and Exit
ESC Exit
v02.58 (C)Copyright 1985-2004, American Megatrends, Inc.

Feature	Options	Description
Quick Boot	Disabled Enabled	Allow BIOS to skip tests while booting
Quiet Boot	Disabled Enabled	Disabled: Display normal POST messages Enabled: Display OEM logo
Add-on ROM Display Mode	Force BIOS Keep Current	Set display mode for option ROM
Bootup Num-Lock	Off On	Select power on state for Num-Lock
PS/2 Mouse Support	Disabled Enabled	Select support for PS/2 mouse
Typematic Rate	Fast Slow	Select the speed rate of typematic
Wait for " F1 " if error	Disabled Enabled	Wait for F1 key to be pressed if error occurs
Hit " DEL " Message Display	Disabled Enabled	Display " Press DEL to run Setup " in POST
Interrupt 19 Capture	Disabled Enabled	Enabled: allows option ROMs to trap interrupt 19

5-8 Security Menu



Security Menu 1: Change Supervisor Password



Security Menu 2: Change User Password



Security Menu 3: Clear User Password



Security Menu 4: Boot Sector Virus Protection

Feature	Options	Description
Change Supervisor Password		Install or change the password
Change User Password		Install or change the password
Clear User Password		Setup: check password while invoking setup Always: check password while invoking setup as well as on each boot
Boot Sector Virus Protection	Disabled Enabled	Enable/Disable boot sector virus protection

5-9 NorthBridge Chipset Configuration Menu



5-9.1 Memory Configuration Submenu



Feature	Options	Description
Memclock Mode	Auto Limit	It can be set by the code using AUTO, or if you use LIMIT, you can set one of the standards.
MCT Timing Mode		See 4-9.1.1
User Config Mode		See 4-9.1.1
Bank Interleaving	Auto Disabled	Interleaving allows memory accesses to be spread out over BANKS on the same node, or across NODES, decreasing access contention
Burst Length	8 Beats 4 Beats 2 Beats	Burst length can be set to 8 or 4 beats. 64 bit Dq must use the 4 beats
Enable Clock to All DIMMs	Disable Enable	Enable unused clocks to DIMMs even memory slots are NOT populated

5-9.1.1 MCT Timing Mode Submenu



MCT Timing Mode



User Config Mode

5-9.2 ECC Configuration Submenu



Feature	Options	Description
DRAM ECC Enable	Disabled Enabled	DRAM ECC allows hardware to report and correct memory errors automatically maintaining system integrity.
L2 Cache BG Scrub	Disable 40ns 80ns 160ns 320ns 640ns 1.28us 2.56us 5.12us 10.2us 20.5us 41.0us 81.9us 163.8us 327.7us 655.4us	Allows the L2 date cache ram to be corrected while idle.
Date Cache BG Scrub	See above	Allows the L1 date cache ram to be corrected while idle.

5-9.3 IOMMU Mode Submenu



Feature	Options	Description
IOMMU Mode	Disabled	
	Best Fit	
	Absolute	

5-10 Power Menu


Main Advanced PCIPnP Boot Security Chipset Power Exit
Power Management/APM [Enabled]
Power Button Mode [On/Off]
Video Power Down Mode [Suspend]
Hard Disk Power Down Mode [Suspend]
Hard Disk Time Out (Minute) [Disabled]
LAN & PME# Resume [Enabled]
RTC Resume [Disabled]
Resume On PS2 Device [Enabled]
Restore on AC/Power Loss [Last State]
PXE Detect [Disabled]
Enable or disable APM
↔ Select Screen
↑↓ Select Item
+- Change Option
F1 General Help
F10 Save and Exit
ESC Exit
v02.58 (C)Copyright 1985-2004, American Megatrends, Inc.

The Power menu items allow you to change the power management settings. Select an item then press Enter to display the configuration options.

5-11 Exit Menu


BIOS SETUP UTILITY
Main Advanced PCIPnP Boot Security Chipset Power Exit
Exit Options
Save Changes and Exit
Discard Changes and Exit
Discard Changes
Load Optimal Defaults
Load Failsafe Defaults
Exit system setup after saving the changes.
F10 key can be used for this operation.
↔ Select Screen
↑↓ Select Item
Enter Go to Sub Screen
F1 General Help
F10 Save and Exit
ESC Exit
v02.58 (C)Copyright 1985-2004, American Megatrends, Inc.

Feature	Description
Save Changes and Exit	Exit system setup after saving the changes F10 key can be used for this operation
Discard Changes and Exit	Exit system setup without saving the changes ESC key can be used for this operation
Discard Changes	Discard changes done so far to any of the setup question F7 key can be used for this operation
Load Optimal Defaults	Load optimal default values for all the setup questions F9 key can be used for this operation
Load Failsafe Defaults	Load Failsafe default values for all the setup questions F8 key can be used for this operation

Important

Any wrong values setting may cause system to malfunction. Therefore, IWILL suggests loading optimal defaults while any error happens.


BIOS SETUP UTILITY
Main Advanced PCIPnP Boot Security Chipset Power Exit
Exit Options
Save Changes and Exit
Discard Changes and Exit
Discard Changes
Load Optimal Defaults
Load Failsafe Defaults
Load Optimal Default values for all the setup questions.
F9 key can be used for this operation.
Load Optimal Defaults?
[Ok] [Cancel]
↔ Select Screen
↑↓ Select Item
Enter Go to Sub Screen
F1 General Help
F10 Save and Exit
ESC Exit
v02.58 (C)Copyright 1985-2004, American Megatrends, Inc.

Chapter 6 Technology Support

If a problem arises with yours system during Installation or OS operating, you should ask your dealer for help first as your system has most likely be configured by them. They always have the best idea and quick response for your symptoms. If your dealer is near to your locations, you should bring your system to them to have it quickly serviced instead of attempting to solve the problem by yourself.

1. Go to IWILL® website at www.iwill.net and navigate to this product page which contains links to product updates such as Jumper settings or BIOS updates.
2. FAQ sections on IWILL® Website are often helpful since other user's questions are often your own.
3. Email us at: support@iwill.net and we will try to answer your questions within 24

Three years Warranty

If any problems occur during the product's warranty period, consult your system vendor or distributor before contacting IWILL®. The warranty covers normal customer use of the product. The warranty does not cover damages sustained during shipping or failure due to alteration, misuse, abuse, or improper maintenance of the unit.